

This console will control two-way Land Mobile Radio System Communication remotely. The features are as follow:

- Repeater control on the air
- Radio control on the air
- Program scrambler on the air

Repeater Control On The Air Features :

- Repeater enable or disable
- Change, enable or disable PL
- Control Link enable or disable
- Repeater Channel Change
- Monitor Power Supply
- ID Repeater
- Report Status Repeater
- Option : GPS and Scrambler

Radio Control On The Air Features :

- Radio enable or disable *
- Call Alert
- Radio Check
- Alias ID Number
- Data Base User Monitor

Program Scrambler On The Air Features :

- Scrambler ID Monitor *
- Program Scrambler
- Call Alert
- Coded-clear Control

